ACCUSPLIT® EAGLE™ 1020

OPERATING INSTRUCTIONS

Congratulations on taking the first step to wellness with your purchase of an ACCUSPLIT pedometer. It's easy to set up your new pedometer. Just follow the steps below, and start walking!

WEARING YOUR PEDOMETER

While gently holding the belt clip open, slide the pedometer onto your belt or the top edge of your pants or skirt. It should fit snugly and level, above one knee.

Note: The pedometer should be as vertical as possible. Walkers with larger stomachs may find it helpful to wear the pedometer farther back on the body, toward one hip.

To avoid losing or dropping your pedometer, use the included leash and clip to fasten the pedometer securely to your clothing.

Attaching the Leash: Attach the pedometer to the leash by looping the leash around the pedometer belt clip. Next, clasp the waist-band of your clothing with the attached clip. You can also use a safety pin to fasten the leash to your clothing, loop the leash through your belt or belt loop or use a badge holder.


First, loop the pedometer clip
Next, loop the metal clip, then clasp clothing
Or, loop a badge holder, then put into pocket
(Badge holder not included)
Or, loop a belt or belt loop

VIEWING YOUR RESULTS

Once you put on your pedometer, it will automatically begin to record your steps.

Eat Right! Walk More! Live Well!
The ACCUSPLIT Lifestyle



RESETTING YOUR PEDOMETER

Most people prefer to reset step counts daily. To reset: Press RESET button to reset to zero.

REPLACING THE BATTERY

When the display starts to dim or goes blank, it is time to replace the battery. Your pedometer uses one Type L1142 (LR43) 1.5 volt silver oxide battery. To replace:

1. Using a jeweler's screwdriver or fingernail, gently pry battery cover from case, using slot at top of cover.
2. Pull the old battery gently out of its holder. Replace it with a new battery. The battery's positive (+) terminal should be FACE UP while you put it into the pedometer.
3. Slide bottom of battery cover back into place, then snap top of cover back into place.

NO-PROOF-OF-PURCHASE LIMITED WARRANTY

See label on back of unit for details, or check http://support.ACCUSPLIT.com

REGISTER NOW Please return your AE1020 Registration to the Repair Center address in the warranty, and we will let you know about future products.

Email (preferred)
User _____

ACCUSPLIT, Inc. • 3090 Independence Drive, Suite 148 • Livermore, CA 94551 USA
800-935-1996 • 925-290-1900 • FAX 925-290-1930 • www.ACCUSPLIT.com • support@ACCUSPLIT.com